



Tent Pitching Instructions Alto 200



FLYSHEET FIRST PITCHING

1. Assemble the four poles and lay them on the ground.
2. Open flysheet on ground and position tent in desired direction.
3. Insert the long pre-bent pole through the black pole sleeve running across the width of the flysheet. The pole is colour coded to aid identification
4. Insert the two straight poles through the black pole sleeves running diagonally across the rear of flysheet.
5. Insert the remaining pole across the width of the flysheet at the front.
6. Locate the ends of the diagonal poles into the eyelets at the rear of the tent.
7. Push the diagonal poles into an arch from the front of the tent and locate the pole ends into corresponding eyelets on pole anchor strap.
8. Connect the large pre-bent pole across the width of tent into corresponding eyelets.
9. Connect the pole at the front of the tent into corresponding eyelets.
10. Tighten flysheet tension straps at end of each pole.
11. The tent will now be free standing, reposition if required.
12. Peg through webbing loops located at each pole anchor strap using alloy pin pegs. Peg all flysheet pegging elastics. Peg the door strap using the flat-top pegs.
13. Peg out **ALL** guy lines using alloy pin pegs ensuring that guy line fabric attachment points are evenly tensioned.

INNER TENT

1. Open out inner tent inside flysheet and position doorway to correspond with the porch.
2. Starting from the rear corners of the tent, attach the elasticated hooks on the groundsheet to corresponding rings on the flysheet anchor straps.
3. Suspend the inner by linking the toggles to the attachment points on inside of flysheet.
4. Peg out the front of the porch groundsheet.

INNER/FLYSHEET COMBINED PITCHING

- The inner tent and flysheet can remain attached when pitching or packing. However, in humid or very wet weather, the underside of the flysheet may be coated with condensation. If this occurs, it may be advisable to detach the inner and pack it separately to avoid the inner tent becoming wet.

IF YOU HAVE ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or

AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland. PA14 6TD.

UK Consumer Hotline: 0844 811 0535

E-Mail: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.