



Pitching Instructions - Sun Canopy Large

Pitching Instructions

- Assemble the poles & insert into colour coded sleeves.
- Locate one end of the pole in ring & pin system as **Figure 1** below.
- Push poles into an arch from opposite side and locate other pole end on to corresponding pin system on flysheet.
- Tension the webbing strap at the pole end.
- Position the elasticated end of canopy towards tent.
- Position elasticated guy rope sleeve behind the front tent pole.
- Secure in position by pegging out the guy lines.
- Peg out the front of the canopy to tension the material.
- Peg out **ALL** peg points including rings as **figure 2**, and peg out **ALL** guy lines.

**The Vango Sun Canopy is designed for use in lowland sheltered campsites.
Do not pitch in high winds or exposed campsites.**




Figure 1.




Figure 2.

IF YOU HAVE ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or
AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland. PA14 6TD.
UK Consumer Hotline: 0844 811 0535 E-Mail: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.