



Pitching Instructions - Tunnel Canopy

Pitching Instructions

- Assemble the poles; 4 steel uprights and 2 steel curved roof poles.
- Insert the curved roof poles through the sleeves on the canopy.
- Attach the upright poles to the roof poles.
- Locate one end of the pole in ring & pin system as **Figure 1** below.
- Stand the canopy upright and locate other pole end on to corresponding pin system on flysheet.
- Tension the webbing strap at the pole end, and attach pole clips to poles.
- Position the fabric end of canopy towards tent.
- Secure in position by attaching the guy line to the ground on the opposite side of the tent.
- Peg out the front of the canopy to tension the material.
- Peg out **ALL** peg points including rings as **figure 2**, and peg out **ALL** guy lines.

The Vango Tunnel Canopy is designed for use in lowland sheltered campsites. Do not pitch in high winds or exposed campsites.




Figure 1.




Figure 2.

IF YOU HAVE ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or
AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland. PA14 6TD.
UK Consumer Hotline: 0844 811 0535 E-Mail: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.